



Detection, Localization and Picking Up of Coil Springs from a Pile


Keitaro Ono, Takuya Ogawa, Yusuke Maeda
(Yokohama National University)

Shigeki Nakatani, Go Nagayasu, Ryo Shimizu,
Noritaka Ouchi (NHK Spring Co., Ltd.)


Background

■ Robotic Bin Picking

- More flexible than conventional parts feeders
- Suitable to high-mix production
- Many previous studies
 - E.g. [Shroff et al. 2011] [Liu et al. 2012]
- Commercial products available




Not Applicable to Coil Springs



Coil Springs

- Round shape: no vertices, no straight lines
- Succession of identical shapes
- See-through
- Highlights by specular reflection



Those make it difficult to apply conventional bin picking techniques

Objective

To Achieve Robotic Bin Picking of Coil Springs


- Approach: Develop a technique dedicated to coil springs
 - Detection: Highlight-based
 - Localization: Stereo vision
 - Picking

Highlight-based Detection of Coil Springs




- Image binarization to extract highlights

End-face Highlights

Side Highlights




Area-based Discrimination of Highlights



Recognition of Coil Springs


- End-face Highlight

- Coil spring in an upright position
- Ellipse fitting to obtain its representative point



- Side Highlight

- Grouping is necessary



Grouping Side Highlights


- Shape similarity

- Area
- Direction of long axis
- Magnitude of curve

} Calculated with image moments


- Relative positioning

- Constant highlight interval
- In-line alignment





Example: Recognition

- Coil springs are successfully recognized
- False groups of inside highlights are harmless for picking





Localization of Coil Springs

- Recognize coil springs for left and right images separately
- Find stereo correspondence






Group-Level Correspondence

- End-face highlights
 - Correspondence between centers of fitted ellipses
- Side highlight groups
 - Correspondence between group centroids
 - Group similarity must be checked
 - Number of member highlights
 - Y-coordinates of group centroids
 - Average highlight areas
 - Group orientation




Example: Group-Level Correspondence



Highlight-Level Correspondence


- Group-level correspondence cannot be found in some cases



- Highlight-level correspondence for localization
 - Y-coordinates of highlights


Highlight-Level Correspondence for Horizontally Aligned Highlights

- Cannot find unique highlight-level correspondence




Highlight-Level Correspondence for Horizontally Aligned Highlights

- Use original grayscale images to find correct highlight-level correspondence
 - Block matching







Template Region (Left)



Matched Region (Right)₁₅

Example: Highlight-Level Correspondence



Localization of Coil Springs

- Standard triangulation



- Height

$$H = L_0 - Z = L_0 - \frac{fT}{(x_1 - x_r)P_s}$$

- pixel size: P_s
- Distance to ref. plane: L_0
- focal length: f
- baseline length: T
- disparity: $x_1 - x_r$

- Tilt angle $\theta = \cos^{-1} \left(\frac{d_{\text{plane}}}{d_{\text{real}}} \frac{ZP_s}{f} \right)$


- highlight interval d_{plane} [pixel]
- pitch: d_{real} [mm]



Disparity Correction

- Shapes of left and right highlights are not strictly identical
 - Due to positional relationship among a coil spring, the light source and the cameras
- Disparity is corrected using an experimental formula


$$d_p \rightarrow d_p + (a\phi + bd_p + c)$$



Picking Strategy


- Picking Order

- Highest-First
- Try second highest after picking failure



- Picking Approach

- Different approaches depending on tilt angle




Experimental Setup

- CCD Cameras
 - Grayscale
 - 1296×964
- LED Spot Illuminator
- Manipulator
 - RV-1A (Mitsubishi Electric)
- Electric Gripper
 - ESG1-SS-2815 (TAIYO)
- Linux PC
- Coil Springs

18 mm

34 mm



CCD Cam

CCD Cam

LED Illuminator

Manipulator

Chuck


Gripper

Video: Picking Experiment

Bin-picking of Coil Springs with Stereo Vision

Keitaro ONO, Takuya OGAWA, Yusuke MAEDA
(Yokohama National University),
Shigeki NAKATANI, Go NAGAYASU, Ryo SHIMIZU and Noritaka OUCHI
(NHK SPRING CO., LTD.)

Picking Results in Five Experiments



Picking Failures



x4

- Collisions between chuck and part box
- Collisions between chuck and other coil springs
- Collision-free approaching should be implemented

Summary

■ Conclusion

- ❑ A bin picking method dedicated to coil springs was presented
- ❑ Coil springs can be detected with highlights on them and localized with stereo vision
- ❑ Successful bin picking was demonstrated

■ Future Work

- ❑ Collision avoidance to reduce picking failures

